



## **MODELO 3S**

### **BÁSCULA ELECTRONICA COMPACTA**



### **MANUAL DE CALIBRACION**

Versión 1.0

## MANUAL DE CALIBRACIÓN

Para 4 botones:

1. Presionar el botón "ON/TARE" para encender la balanza, cuando el display marque 88888, presione nuevamente el botón "ON/TARE" mientras marca en el display cero.
2. When the zero inner code is between 1000-15000, press "ON/TARE" button again, the reading will be 00000, now put the max. capacity weight of 5kg on the scale, after 3-5 seconds, press "ON/TARE" button again, the scale will display 15000, then the calibration has been done.
3. press "OFF" button to power off the scale.
4. Power on the scale, put the 5kg weight on the scale again and check if the scale show the correct weight, if yes, the calibration succeed, if not, follow step 1-3 again.

For 3 buttons:

1. Keep pressing "MODE" button first, then press "ON/TARE" button to power on the scale, after self-examine, the scale will display the inner code "06000" (the inner code should be within 20000), now loose "MODE" button.
2. Press "ON/TARE" button again, the reading will be 00000, now put the max. capacity weight of 5kg on the scale, after 3-5 seconds, press "ON/TARE" button again, the scale will display 20000, then the calibration has been done.
3. Press "OFF" button to power off the scale.
4. Power on the scale, put the 5kg weight on the scale again and check if the scale show the correct weight, if yes, the calibration succeed, if not, follow step 1-3 again.